

6140 PARTS LIST

REF. NO.	PART NO.	QTY.	DESCRIPTION
1.	00092	1	Bolt 1/4"NC X 1/2" GR5 Hex
2.	00290	1	Bolt 5/8"NC X 2" GR5 Hex
3.	15384-76	1	B & W UL Frame
4.	15385-76	1	Bolt Lock Plate

Please order replacement parts by PART NO. and DESCRIPTION.

READ *complete manual CAREFULLY BEFORE attempting operation.*

DEMCO • 4010 320th St. • Boyden, IA 51234 • www.demco-products.com PH: (712) 725-2311 • Toll Free: 1-800-543-3626 • FAX: (800) 845-6420



1. To install the adapter, lay a straight edge on top of the truck bed and measure from the straight edge to the top of cross pin.



2. Adjust the top bolt so the top of the bushing measures approximatly 1/16" less than the measurement from the straight edge to pin. Pull the B&W pin and install adapter into the socket. Allow the B&W hitch pin to slide back into place. If pin in not fully going back into place, the adapter my need to be adjusted.



3. Once the B&W hitch pin fully returns into the adapter, tighten the top bolt to 20-25 ft lbs. and use the bolt retainer with 1/4" bolt to hold bolt into place as shown.

Important:

We **DO NOT** recommend the use of an auto sliding hitch to be used with the B&W UL rail hitch adapter.