



# CRE3000 RUBBER EQUALIZER INSTALLATION INSTRUCTIONS

The MORryde CRE3000, Compression Rubber Equalizer with 3.0" of suspension travel\* is the affordable way to upgrade, by replacing the steel equalizers with rubber compression springs that absorb more road shock and provide increased suspension travel.

## Required Tools:

- Torque wrench
- 11/16" socket & 13/16" wrench
- Floor jacks
- Safety stand

**STEP 1** Using appropriately rated jacks to support the trailer, jack unit up and support frame with safety stands and support axles with floor jacks.

**STEP 2** Remove shoulder bolt from frame hanger and remove shackle links.

**STEP 3** Replace stock equalizer with CRE3000. Replace shoulder bolt. Reinstall shackle links and tighten all nuts. Torque to 40 ft-lbs.

**STEP 4** Remove jacks and supports from frame and axles.

