

FRAME MOUNTING BRACKET KITS



NO DRILL ATTACHMENT INDICATED IN BLUE

• Contact Demco at 1-800-543-3626 if your installation bracket kit is not listed.

VEHICLE	UMS-SERIES UNDER BED MOUNT	PREMIER-SERIES	SL-SERIES
FORD			
2017 Ford F250/350 "Super Duty" (6-1/2' & 8' Boxes)	Coming Soon	8552031	Coming Soon
2011-2016 F250/350 "Super Duty" (6 1/2' & 8' Boxes)	8551000	8552000	8553000
2011-2015 F450 "Super Duty" (6 1/2' & 8' Boxes)	8551000	8552000	8553000
2005-2010 F250/350 "Super Duty" (6 1/2' & 8' Boxes)	8551000	8552001 or 8552002	8553001
2008-2010 F450 "Super Duty" (6 1/2' & 8' Boxes)	8551000	8552001 or 8552002	8553001
2015-2016 F150 (5 1/2', 6 1/2' & 8' Boxes)	N/A	8552028	8553015
2004-2014 F150 (5 1/2', 6 1/2' & 8' Boxes)	8551001	8552003 or 8552004	8553002
2001-07 F450/550 "Chassis Cab"	N/A	8552005	Not recommended
1999-2004 F250/350 "Super Duty" (6 1/2' & 8' Boxes)	8551000	8552006	8553003
1992-98 F350 (6 1/2' & 8' Boxes)	N/A	8552005	8553003
1997-98 F250 "Heavy Duty" (6 1/2' & 8' Boxes)	N/A	8552005	8553003
1997-03 F250 "Light Duty" (6 1/2' & 8' Boxes)	N/A	8552009	8553004
1997-2003 F150 (6 1/2' & 8' Boxes)	N/A	8552009	8553004
1989-96 F150/250 (6 1/2' & 8' Boxes)	N/A	8552005	8553005
2000 & earlier Ranger (6 1/2' Boxes)	N/A	N/A	8553006
1973-88 F Series (6 1/2' & 8' Boxes)	N/A	8552005	8553003
CHEVROLET/GMC			
2014-2017 Silverado & Sierra 1500 (6 1/2' and 8' Boxes) No Double Cab	8551007	8552027	8553014
2014-2017 Silverado & Sierra 1500 (6-1/2 Box) Double Cab	8551008	8552027	8553014
2014-2017 Silverado & Sierra 1500 (5 1/2' Box)	8551008	8552027	8553014
2011-2016 Silverado/Sierra 2500 & 3500 HD (6 1/2' box only)	8551002	8552011	8553007
2011-2016 Silverado/Sierra 2500 & 3500 HD (8' box only)	8551003	8552011	8553007
2001-2010 Silverado/Sierra 2500 & 3500 HD (6 1/2' & 8' Boxes) (Includes New Body Style)	8551004	8552009 or 8552012	8553004
2007-2013 Silverado & Sierra 1500 (6 1/2' and 8' Box) (tube frame)	8551005	8552009 or 8552013	8553004
2007-2013 Silverado & Sierra 1500 (5 1/2' Box)	8551008	8552009 or 8552013	8553004
1999-2007 Silverado & Sierra 1500 / 2500 (6 1/2' & 8' Boxes)	8551004	8552009	8553004
2001-07 Silverado/Sierra 1500 HD (6 1/2' & 8' Boxes)	8551004	8552009	8553004
2004-06 Silverado/Sierra 1500 (5 1/2' Box)	8551008	8552009	8553004
1988-2001 3500 (6 1/2' and 8' Box)	N/A	8552009	8553009
1988-98 1500 / 2500 (8' Box)	N/A	8552009	8553009
1988-98 1500 / 2500 (6 1/2' Box)	N/A	8552009	8553009
1987 & earlier S-10 (6 1/2' Box)	N/A	N/A	8553003
1987 & earlier (6 1/2' & 8' Boxes)	N/A	8552014	Not recommended
DODGE			
2009-2017 Ram 1500 (5 1/2', 6 1/2' & 8' Boxes) No Air Suspension Includes Diesel	N/A	8552030	8553010
2002-2008 Ram 1500 (4x2 & 4x4)(6 1/2' & 8' Boxes)(Includes Mega Cab)	8551005	8552015 or 8552016	8553004
2014-2017 Ram 2500 (4x2 & 4x4)(6 1/2' & 8' Boxes) (Includes Mega Cab) (Includes Auto Level Rear Air Suspension)	N/A	8552025	8553016
2013 Ram 2500 (4x2 & 4x4)(6 1/2' & 8' Boxes) (Includes Mega Cab)	8551005	8552015 or 8552023	8553004
2003-2012 Ram 2500 (4x2 & 4x4)(6 1/2' & 8' Boxes) (Includes Mega Cab)	8551005	8552015 or 8552016	8553004
2013-2017 Ram 3500 (4x2 & 4x4)(6 1/2' & 8' Boxes) (Includes Mega Cab)	8551006*	8552026	8553013*
2003-2012 RAM 3500 (4x4 only)(6 1/2' & 8' Boxes) (Includes Mega Cab)	8551005	8552015 or 8552016	8553004
2003-2012 Ram 3500 (4x2 only)(6 1/2' & 8' Boxes) (Includes Mega Cab)	8551005	8552017	8553004
1994-2001 Ram 1500/2500/3500	N/A	8552009	8553003
1994-2002 Ram 2500/3500 (6 1/2' & 8' Boxes)	N/A	8552009	8553003
1993 & earlier Ram (6 1/2' & 8' Boxes)	N/A	8552009	8553003
2005 Dakota (6 1/2' Box)	N/A	8552019	8553003
2003-04 Dakota (6 1/2' Box)	N/A	8552005	8553003
2002 & earlier Dakota	N/A	8552009	8553003
TOYOTA			
2001 & earlier Tacoma	N/A	N/A	8553012
2001-06 Tundra (6 1/2' & 8' Boxes)	N/A	8552009	Not recommended
2007-2016 Tundra (5 1/2', 6 1/2' & 8' Boxes)	N/A	8552020	N/A
2000 & earlier T100	N/A	8552009	8553012
NISSAN			
2004-2015 Titan (5 1/2', 6 1/2', 7' & 8' Boxes)	N/A	8552021	N/A

*Not with "Auto Level Rear Air Suspension" option