



941 Oak Street · Elkhart, In 46514 · ph (574) 264-9674 · fax (574) 264-9859

INSTALLATION AND MAINTENANCE INSTRUCTIONS FOR THE

SPRAY-PORT TM

(Cold water only auxiliary spray down outlet and hatch)

Thank you for choosing the Spray-A-Way Spray Port; the easy-to-use, indispensable camping tool! By following these simple installation and maintenance procedures, your Spray-A-Way will give you years of service and convenience.

1. INSTALLATION

- a. The Spray-Port unit installs into a 2 3/4" round hole and extends approximately 6" into the vehicle (allowing for the plumbing hook-up).
- b. It is recommended the hinge side of the hatch door should be at the top.
- c. A sealant should be applied around the frame of the hatch, in the area of the screw holes, before installation. Do not use so much sealant that it warps the hatch door frame.
- d. Screws should be installed in *all* the screw holes and then tightened in a random manner (not in a clockwise manner) to be sure the hatch is not distorted.
- e. *Screws must not be over tightened!*
- f. An in-line shutoff valve is suggested between the vehicle water supply and the Spray-A-Way inlet check valve on the rear of the unit to facilitate drainage.

2. MAINTENANCE

- a. Your Spray-A-Way should be drained for transport or if freezing weather is expected. To drain simply turn off the inline water supply valves, remove the sprayer nozzle from the coil hose and insert the hose into the brass quick connect. This will release the quick connect valve stopper. Hold the open end of the hose near the ground and drain the system.**
- b. If the brass quick release valve leaks or drips, it is likely a small particle of dirt or plastic is caught in the check valve mechanism. Simply remove the sprayer from the end of the coil hose then connect and disconnect the hose a few times. This will flush the line and clear the valve.**
- c. If your Spray-Away/Spray-Port has not been used for some time, the valve inside the quick connect may be seized. This is an easy fix. Just squirt a little WD-40 into the quick connect, insert a small screwdriver into the center and tap the screw driver lightly with a hammer. This should free the valve and/or release any pressure and allow the valve to open. Lubricate periodically.**
- d. Replacement parts and Spray-A-Way units are available online at www.dwincorp.com.**

NOTICE: The Spray-Away, Spray-Port and Hot/Cold Spray- Port coil hoses are intended for interim use *outside* of the RV. Disconnect any hoses from the quick connector when not in use. D&W Inc. is not responsible for damage occurring if hoses are left connected and unattended.

Revised 04/12