

 When you are ready to leave this campsite, place ReVo Leveler on the nest and press the power button to turn it on.



Press the CON button
arrow will show to
raise or lower the trailer
to reach the connect
position



 Use the tongue jack or landing jacks to raise or lower your trailer.
Your trailer is at the correct connect position when both arrows are

solid green.

- Connect your tow vehicle to your trailer. No more in and out of the vehicle to correctly position the trailer to connect.
- Press the power button to turn ReVo Leveler off.
- Remove ReVo Leveler from the nest and place it into storage for the next camping trip

www.revoleveler.com

info@revoleveler.com

Toll Free: 844-RV-LEVEL

844-785-3835

What's Included:



ReVo Leveler, Left and Right Hand Nest, Charger and Cable, Back Cover, Storage Bag, Sun Shield, Height Adjustments Label, and Printed Directions.



 Revo Leveler can be used on the left side of the trailer. Only one nest is needed per trailer



 Revo Leveler can be used on the right side of the trailer. Only one nest is needed per

trailer.

- Units can be displayed in inches or centimeters
- Refer to printed instructions included with unit or website for programming the initial positions.



"Let me level with you"

"Will tell you what board thickness is needed and which side of the trailer needs raised to be level left to right".





"Set your trailer up on your campsite before your camping neighbors have time to come over and help"

"Can be used on bumper pull and 5th wheel travel trailers"



