


RH Spout Cap Shown

Awning
Channel



Non Awning
Channel



Verticle
Guide



J Channel

RV Rain Gutter Spout

Installation Instructions

1. Remove 2-3 screws from right end of Rain Gutter Channel
2. Remove only enough putty tape or sealant (approx. 1 1/4") from back of Rain Gutter Spout behind the Rain Gutter Channel
3. Using the verticle guide as a reference (see drawing) position the right Rain Gutter Spout behind the Rain Gutter Channel
4. Apply new putty tape or sealant to back of right Rain Gutter Spout
5. Reinstall screws thru Rain Gutter Channel and right Rain Gutter Spout
6. For left Rain Gutter Spout installation, repeat steps 1 thru 5