


DROP LEAF SUPPORT INSTALLATION INSTRUCTIONS



DIMENSION "B"	1 1/2"	2"	2 1/2"
DLS SIZE	DIMENSION "A"		
6 INCH	2 1/8"	1 13/16"	1 5/16"
8 INCH	2 1/4"	1 15/16"	1 7/16"
10 INCH	3 9/16"	3 3/16"	2 13/16"
12 INCH	3 11/16"	3 5/16"	2 15/16"