



DOOR PANELS FOR REFRIGERATOR MODELS RM3762 RM3962

USA
SERVICE OFFICE
Dometic Corporation
1120 North Main Street
Elkhart, IN 46514

**For Service Center
Assistance Call:**
800-544-4881



INSTALLATION INSTRUCTIONS

DOOR PANELS
3106863.156(X)
3106863.164(X)

REVISION A
Form No. 3312203.155 07/18
©2018 Dometic, LLC
LaGrange, IN 46761

INSTALLATION INSTRUCTIONS

Installing the door panels


The refrigerator is delivered without door panel(s). Before starting the mounting work, read this instruction thoroughly and check that the panel dimensions are in compliance with those given in the table below.


Panel dimensions max. thickness 5/32" (4 mm)					
Model		Height		Width	
		max	min	max	min
RM3762					
upper	inch	17-3/64	16-31/32	23-25/32	23-11/16
	mm	433	431	604	602
lower	inch	32-7/16	32-23/64	23-25/32	23-11/16
	mm	824	822	604	602
RM3962					
upper	inch	17-3/64	16-31/32	23-25/32	23-11/16
	mm	433	431	604	602
lower	inch	41-39/64	41-9/16	23-25/32	23-11/16
	mm	1057	1055	604	602

See page 3. for installation steps.


INSTALLATION INSTRUCTIONS

To install the door panel, follow these steps:

-  1. Remove the decoration strip by inserting a finger in the plastic profile and pull.



2. Open the door 90 degrees.
3. Insert the door panel's edges into the grooves of the door frame. Push the panel sideways until the edge of the panel is fitted into the opposite side groove.




4. Snap on the decoration strip.



5. Snap on the handle.



To replace a mounted door panel, follow these steps:

-  1. Detach the handle by using a flat blade screwdriver to gently push the two tabs away.



2. Remove the decoration strip, according to the previous instruction "To install the door panel", step 1.
3. Remove the door panel.
4. Install the new panel according to the previous instruction "To install the door panel", steps 3-5.