



### **Table of Contents**

Introduction 1
Safety Information 1
Parts List
Resources Required 3
Prior to Installation
Installation3Fixed Faucet3Pull Down Faucet4
Operation5Fixed Faucet5Pull Down Faucet6
Troubleshooting Chart 7
Maintenance 7
Notes

# Flow Max<sup>™</sup> Faucets Installation and Owner's Manual

(For Aftermarket Applications)

### Introduction

Add a splash of modern to your kitchen or bath with a Flow Max Faucet by Lippert. Available in a variety of spout constructions, including coiled spring and high-arched, we are challenging how the world feels about faucets. Constructed with quality stainless steel or black matte finish, these sleek faucets are designed for maximum lifespan and durability.

# Safety Information

# A CAUTION

THE "CAUTION" SYMBOL ABOVE IS A SIGN THAT A SAFETY RISK IS INVOLVED AND MAY CAUSE PERSONAL INJURY AND/OR PRODUCT OR PROPERTY DAMAGE IF NOT SAFELY ADHERED TO AND WITHIN THE PARAMETERS SET FORTH IN THIS MANUAL

# 

MOVING PARTS CAN PINCH, CRUSH OR CUT. KEEP CLEAR AND USE CAUTION.

1



(For Aftermarket Applications)

### **Parts List**



<u>719323</u> - Spring Faucet Pull Down Installation Black matte - <u>2021090598</u>



2022007782 - Waterfall Bathroom Fixed Installation Black matte - 2021090599





719324 - Curved Gooseneck Fixed Installation Black matte - 2021090601



692179 - Luminary Lavatory Fixed Installation



2022007783 - Pull Down Faucet Black Matte - <u>2021090602</u>

696320 - Black Hose Kitchen Faucet



719333 - Bullet Pull Down Pull Down Installation Black matte - 2021090600



719325 - Square Gooseneck Fixed Installation Black matte - 2021090597

Part #	Description		
Stainless Steel Finish			
<u>719323</u>	Spring Faucet, Single Hole		
<u>719324</u>	Curved Gooseneck Faucet, Single Hole		
<u>719325</u>	Square Gooseneck Faucet, Single Hole		
<u>719333</u>	Bullet Pull Down Faucet, Single Hole		
<u>2022007782</u>	Waterfall Bathroom Faucet, Single Hole		
<u>692179</u>	Luminary Lavatory Faucet, Single Hole		
<u>2022007783</u>	Pulldown Faucet, Single Hole		
Black Matte Finish			
<u>2021090598</u>	Spring Faucet, Single Hole		
<u>2021090601</u>	Curved Gooseneck Faucet, Single Hole		
<u>2021090597</u>	Square Gooseneck Faucet, Single Hole		
<u>2021090600</u>	Bullet Pull Down Faucet, Single Hole		
<u>2021090599</u>	Waterfall Bathroom Faucet, Single Hole		
<u>2021090602</u>	Pulldown Faucet, Single Hole		
<u>696320</u>	Black Hose Kitchen Faucet		



(For Aftermarket Applications)

## **Resources Required**

- · Phillips screw driver
- · Adjustable wrenches
- Bucket
- Flashlight
- · Safety glasses

# **Prior to Installation**

**1.** Shut off the hot and cold water outlet supply valves for the existing faucet, typically located below the sink.

**2.** Relieve any pressure from the existing faucet by turning the existing faucet on and off.

**3.** Place a bucket under the sink, under the supply lines' supply valves to catch any excess water.

**4.** Using an adjustable wrench, disconnect the supply lines from the outlet water supply valves. Place the supply lines into the bucket to drain any excess water.

**5.** Under the sink, disconnect the mounting hardware for the existing faucet and remove the faucet from the deck.

**6.** Make sure the deck around the mounting hole area is clean, dry and free from any debris.

# Installation

#### **Fixed Faucet**

**1.** Unscrew the metal collar with the two screws from the faucet base and set aside (**Fig.1A**).

**2.** Remove the metal washer **(Fig.1B)** from the base and set aside.


NOTE: Leave black rubber washer (Fig.1C) on faucet.



**3.** Place the faucet supply lines through the mounting hole on the deck, making sure the black rubber washer and faucet base are seated firmly on the deck of the sink **(Fig.2A)**.


**4.** Position the faucet base so the handle is to the right side of the faucet base **(Fig.2B)**.

**NOTE:** The handle can be positioned to the left of the faucet base but is typically placed to the right. Placing the handle in the middle may cause severe burns depending on where the faucet neck is located when turning on the water.



#### Fig.2

**5.** Under the sink, slide the metal washer **(Fig. 1B)** over the supply lines onto the base of the faucet. Make sure the metal washer is flush against the underside of the sink deck and covering the mounting hole **(Fig.3A)**.



Rev: 08.08.22

CCD-0001241

Fig.1



(For Aftermarket Applications)

**6.** Make sure the two screws on the collar are evenly inserted and are flushed with the top of the collar **(Fig.4A)**.



#### Fig.4

**7.** Screw the collar onto the faucet base all the way up to the metal washer **(Fig.5A)**.

**NOTE:** Make sure the handle of the faucet is placed in the desired position.

**8.** Using a Phillips screwdriver, tighten the two screws **(Fig.5B)** on the collar to hold the collar into place.



#### Fig.5

**NOTE:** The red-marked supply line is for hot water and the blue-marked supply line is for the cold water.

**9.** Thread the nut on the hot water supply line onto the hot water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.

**10.** Thread the nut on the cold water supply line onto the cold water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.

**11.** Turn the hot and cold water outlet supply valves back on and check for any leaks.


#### **Pull Down Faucet**

**1.** Unscrew the black plastic coupler from the faucet base and slide off from the faucet assembly.

**NOTE:** Wiggle the plastic collar off the supply lines one line at a time.

2. Slide the clear plastic washer off the faucet assembly.

**3.** Place the faucet supply lines through the mounting hole on the deck, making sure the black rubber washer and faucet base are seated firmly on the deck of the sink **(Fig.6A)**.



#### Fig.6

**4.** Under the sink, slide the clear plastic washer over the supply lines up to the underside of the sink deck and covering the mounting hole (**Fig.7A**).



4



(For Aftermarket Applications)

**5.** Slide the black plastic collar back onto the supply lines, inserting one supply line at a time.

**NOTE:** Make sure the inside threads of the black plastic coupler are at the top.

**6.** Screw the black plastic collar all the way up the faucet base until it will no longer turn **(Fig.8A)**.



#### Fig.8

**NOTE:** The red marked supply line is for hot water and the blue marked supply line is for the cold water.

**7.** Thread the nut on the hot water supply line onto the hot water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.

**8.** Thread the nut on the cold water supply line onto the cold water outlet supply valve and tighten with an adjustable wrench. Do not over tighten.

**9.** Turn the hot and cold water outlet supply valves back on and check for any leaks.

## Operation

#### **Fixed Faucet**


1. Pull the lever away from the faucet to turn it on (Fig.9A).



#### Fig.9

2. Move the lever towards you for hot water (Fig. 10) and away from you for cold water (Fig. 11).

**NOTE:** Located on the front of the lever is a "H" for hot water and a "C" for cold water. Move the lever in the direction of the desired temperature.





Flow Max<sup>™</sup> Faucets Installation and Owner's Manual (For Aftermarket Applications)

3. Push the lever in towards the faucet to shut the water off (Fig.12A).




Fig.12

#### **Pull Down Faucet**

1. Pull the lever away from the faucet to turn it on (Fig.13A).




Fig.13

2. Move the lever towards you for hot water (Fig.14) and away from you for cold water (Fig.15).

**NOTE:** Located on the front of the lever is a "H" for hot water and a "C" for cold water. Move the lever in the direction of the desired temperature.




Fig.14

Fig.15

3. To use the spray wand pull down and out on the faucet head.

4. Press and release the button in on the lower portion of the faucet head (Fig.16A) for spray mode. Press and release the button again for stream mode.



#### Fig.16

5. Replace the faucet head by gently guiding the hose back into the faucet neck and insert into clip, if applicable.



(For Aftermarket Applications)

**6.** To shut the water off push the lever in towards the faucet **(Fig.17)**.




Fig.17

### Maintenance 1. Clean the faucet periodically.

**2.** Apply a coat of toothpaste to a wet soft-bristle toothbrush.

**NOTE:** Avoid abrasive cleaners, steel wool and chemical solutions as these will dull the finish and void the warranty.

3. Brush over the surface of the faucet.

**4.** After cleaning, rinse the faucet thoroughly with water, washing away all the remains of the paste.

5. Rub dry with a soft cloth.

### **Troubleshooting Chart**

Vibration caused by driving or transporting can loosen plumbing and hardware. Check for loose system components. Many symptoms can be resolved by tightening hardware. Use care not to over-tighten. Refer to the chart for troubleshooting tips.


What is happening?	Why?	What should be done?
Irregular Flow	Blockage at the aerator.	For further instructions: <u>Reference: CCD-0004351</u>
	Cartridge is clogged.	For further instructions: <u>Reference: CCD-0004317</u>
There is a leak from the aerator when the faucet is on.	The aerator does not fit correctly on the faucet.	Remove aerator and re-install.
The aerator has irregular or reduced water flow.	The aerator is dirty.	Remove aerator and clear debris.

7



Flow Max<sup>™</sup> Faucets Installation and Owner's Manual (For Aftermarket Applications)

### **Notes**





Manual information may be distributed as a complete document only, unless Lippert Components provides explicit consent to distribute individual parts.

All manual information is subject to change without notice. Revised editions will be available for free download at <u>lippert.com</u>. Manual information is considered factual until made obsolete by a revised version.

Please recycle all obsolete materials and contact Lippert Components with concerns or questions.