




# 5th Wheel Side Rail Assemblies

5004 UMS SIDE RAIL




**READ** complete manual CAREFULLY BEFORE attempting operation.

### **WARRANTY POLICY & REGISTRATION**


Go online to www.demco-products.com to review Demco warranty policies and register your Demco product.

# 6004 Side Rail Assembly Instructions

- 1. Loosely bolt the main Autoslide assembly to the side rails with spacer plates using the 1/2" x 1 3/4" bolts, flat washers, and lock nuts provided in the side rail bolt package at the predetermined height using the bolt pattern guide in below. **NOTE:** On highest setting, use 6 bolts. The 4 along the top row are to fasten to hitch assembly and the bottom 2 are to fasten the side rail brace to side rail to retain locking pins. (1/4" & 3/8" thick spacers are supplied for adjusting the hitch mount width with the bed pockets. You may mix and match the different shim thicknesses for fine tuning the fit).
- 2. Tighten all bolts.
- 3. Unlock locking pins and insert the hitch assembly into the base rails and test for fit. If the pins are to narrow to drop in, follow the alignment procedure on page 3.
- 4. Proceed to base rail install procedure as provided in the base rail installation kit.




### 6004 Parts Breakdown




Please order replacement parts by PART NO. and DESCRIPTION

**IMPORTANT NOTE:** Apply a little grease or lubricant to the part of the pins that insert into the base rails to help maintain smooth operation and rotation of pins and to protect from the elements. Turn the pins occasionally to prevent them from seizing.



## **Alignment Procedure**

If the side plate pins do not drop into the base rail holes because they are not out far enough, then undo one side and add a 1/2" flat washer in between the main frame and the side spacer plate at each bolt attachments hole. Tighten and try reinstalling into the base rails. If necessary, do the same on the other side to shim out further if needed.





P.O. BOX 189 4010 320th St., BOYDEN, IA. 51234 PH: (712) 725-2311

FAX: (712) 725-2380 TOLL FREE: 1-800-54DEMCO (1-800-543-3626) www.demco-products.com

Go online to www.demco-products.com for Demco warranty policies & product registration.