MTI INDUSTRIES, Inc. TM

RV PROPANE GAS DETECTOR

MODEL 20-441 USER'S MANUAL

IMPORTANT PLEASE READ CAREFULLY

This manual contains important information. Anyone who installs this unit for use by others must leave this manual with the owner. **Do not throw this out.**



Manual #204207-6

RECREATIONAL VEHICLE GAS DETECTOR

FILE NO. 151449

AMP

IMPORTANT: Always follow the operation and safety instructions of the gas appliance manufacturer.

⚠ WARNING

CONNECT ONLY TO WIRING THAT CANNOT BE TURNED OFF BY A WALL SWITCH OR GROUND FAULT PROTECTOR.

IMPORTANT: Failure to follow the installation instructions may void the warranty.

SPECIAL FEATURES OF THE MTI INDUSTRIES TM GAS DETECTORS

This MTI Industries TM propane gas Detector is listed by Underwriters Laboratories, Inc. for use in recreational vehicles. Other explosive gases detected but not tested by Underwriters Laboratories include Acetone, Alcohol, Butane, Gasoline all of which you may have in your Trailer, Truck Camper, Van Camper or Motorhome.

When dangerous levels of propane gas (< 25% LEL) are detected the Detector signal will activate. A reset/mute circuit can be activated to temporally silence the Detector while you ventilate.

RECOMI	MENDED WII	RE GAUGE14 GA	•
POWER S	SUPPLY	12 vDC	7
WIRE CO	LOR CODE:	RED SUPPLY (+)	
		BLACK GROUND (-)	
FUSED	CIRCUIT	MAXIMUM15	5

⚠ WARNING LIMITATIONS OF PROPANE GAS DETECTORS

THIS UNIT will not work without power. Examples causing no power are: Cut lead wires, faulty circuit connection, a blown or missing fuse, improper supply (+) or ground (-) connections.

This Detector will only indicate the presence of propane gas at the sensor. Explosive gas may be present in other areas.

This Detector may not be heard. The Detector loudness meets or exceeds regulatory standards. However, if this Detector is in remote locations or behind closed doors the Detector may not be heard. Persons who are hard of hearing may not hear the Detector.

This Detector is not a smoke or fire Alarm. It is also not a carbon monoxide alarm.

This Detector is not suitable for installation in hazardous areas as defined in the National Electrical Code.

HOW TO TAKE CARE OF YOUR DETECTOR

To keep your Detector in good working order, you must;

- Test the Detector weekly. (See "TEST PROCEDURE")
- Observe the color of the indicator light on the front of the unit regularly. (See "Operating Instructions")
- Vacuum the dust off the Detector cover weekly, (more frequently in dusty locations), using the soft brush attachment of your vacuum.
- Clean the Detector cover weekly. Hand wash using a damp cloth, or paper towel. Dry with a soft cloth.
- DO NOT SPRAY CLEANING AGENTS OR WAXES directly onto the front panel. This action may damage the sensor, cause an Alarm or cause a malfunction.

WHERE TO INSTALL GAS DETECTORS

This Detector is UL[®] listed for installation in recreational vehicles. Install this Detector near sources of a potential gas leak. Some potential sources are a furnace, water heater, stove or oven. If potential sources of a gas leak are in separated areas, MTI recommends installing a Detector in each area. See Figure 1 and 2.

CAUTION: Propane is heavier than air. For propane gas detection, install this Detector from 4 to 20 inches off the floor.

⚠ WARNING

WHERE <u>NOT TO INSTALL</u> THIS GAS DETECTOR. See Figure 3.


- BEHIND FURNITURE, DRAPES, IN CLOSETS OR AREAS THAT WILL BLOCK AIR FLOW TO THE DETECTOR.
- WITHIN 12 INCHES OF EXTERIOR DOORS, WINDOWS, HEATING OR RETURNS VENTS, OR OTHER DRAFTY AREAS.
- IN OR ON OUTSIDE WALLS
- TO A WALL SWITCH CONTROLLED POWER LINE, GROUND FAULT CIRCUIT OR CIRCUIT BREAKER.
- NOTE: Older homes and RVs may have little or no insulation and therefore are more drafty. Carefully consider mounting locations.

INSTALLATION INSTRUCTIONS

Power Supply 12 vDC. Connect the Detector to a properly fused circuit. All connections must be in accordance with the National Electrical Code.


CAUTION: ONLY USE UL® APPROVED CONNECTORS <u>DISCONNECT POWER UNTIL THE</u> INSTALLATION IS COMPLETE

20-441: REFER TO ("WHERE TO AND NOT TO INSTALL GAS DETECTOR") Install the back plate and drill a ¹/₄" hole for the power leads. Connect the RED (+) power lead to the fused circuit. Connect the BLACK lead to Ground (-). Slide the Detector enclosure onto the mounting plate. Reconnect the power supply.



Alarm Location For Minimum Protection





Do not install

within 12" of vents

OPERATION

Do Not install behind

drapes or furniture

WARNING: This Detector cannot detect propane gas or sound the Alarm for two minutes after it has been turned on.

POWER ON: When powered the LED color will be Green (Operational).

TESTING

WARNING: TEST THE OPERATION OF THIS DETECTOR AFTER THE RECREATIONAL VEHICLE HAS BEEN IN STORAGE, BEFORE EACH TRIP AND AT LEAST ONCE PER WEEK DURING USE.

⚠ WARNING: DO NOT USE A CIGARETTE LIGHTER. THE BUTANE GAS MAY DAMAGE THE SENSOR.

1. Simply press the Test/Mute switch at any time the Detector is powered. The LED should turn RED and the Alarm should sound. Release the switch.

<u>IMPORTANT</u> - If this Detector does not test properly return it immediately for repair or replacement.

ALARM SIGNAL

The Green LED will turn Red and the audible signal will activate whenever the level of propane gas exceeds the Alarm threshold. The unit will continue to Alarm until the gas clears or the Mute switch is pressed. See (Procedures Take During an Alarm and Alarm Signal Mute sections)

ALARM SIGNAL MUTE

Press the TEST-MUTE button when the detector is in Alarm. 1. The audible Alarm signal will stop, 2. the RED Alarm LED will remain on until the gas has dropped below the Alarm point at which time the LED will turn Green, 3. If dangerous gas levels remain after the end of the Mute cycle (about 90 seconds) the Alarm will re-activate.

MALFUNCTION ALARM

A fault in the sensors operation will activate malfunction Alarm. The LED will turn Yellow and the sounder activate.

IMPORTANT: IN THE EVENT OF A
MALFUNCTION ALARM, REMOVE THE
DETECTOR IMMEDIATELY AND RETURN IT
FOR REPAIR OR REPLACEMENT. Do not Use
your RV without a working Gas Detector installed.

LOW POWER OPERATION

This Detector will operate normally down to 8 vDC. Do not operate this Detector below 8 vDC.

PROCEDURES TO TAKE DURING AN ALARM

- 1. TURN OFF ALL GAS APPLIANCES, (STOVE, HEATERS, FURNACE), EXTINGUISH ALL FLAMES AND SMOKING MATERIAL. EVACUATE THE UNIT, LEAVE DOORS AND WINDOWS OPEN.
- 2. TURN OFF THE PROPANE TANK VALVE.
- 3. DETERMINE AND REPAIR THE SOURCE OF THE LEAK. SEEK PROFESSIONAL HELP IF NECESSARY.

CAUTION - DO NOT RE-ENTER UNTIL THE PROBLEM IS CORRECTED.

LED AND SOUNDER SIGNALS

Color	Alarm Operation	Sounder
Solid Green	Normal	Off
Solid Red	Alarm	Continuous
Solid Yellow	Malfunction	Continuous

TROUBLE SHOOTING GUIDE

PROBLEM	CAUSE AND SOLUTION
LED OFF	1. FAULTY WIRE CONNECTION
	2. REVERSE POLARITY
	3. BAD OR MISSING FUSE
	4. DEAD BATTERY
NO SOUND I	N TEST 1. Contact Customer Service
NO RED LED	IN TEST 1. Contact Customer Service
ALARMS AF	TER 1. Contaminated Sensor. Press
WARM UP W	ITHOUT the Test/mute Switch and
GAS PRESEN	VT Wait 90 seconds

1.Contact Customer Service

AUDIBLE ALARM

NO RESET

WITH YELLOW LED

SPECIFICATIONS

POWER SUPPLY 12 vDC CURRENT DRAW - STANDBY 75 mA @ 12 vDC OPERATIONAL TEMPERATURE -31° F to 150° F -35° C to 66° C RELATIVE HUMIDITY 15% to 93% **AUDIBLE OUTPUT** 85 dB @ 10 feet VISUAL OPERATIONAL SIGNAL GREEN VISUAL ALARM SIGNAL RED VISUAL MALFUNCTION SIGNAL YELLOW ALARM TRIGGER < 25% of the LEL of Propane CASE DIMENSIONS 3 1/2" W x 2 1/2" H x 1 1/2" D CASE MATERIAL GA Gulf PVC SP- 7107 WHT 306 FLAME RATING 94 5V WARRANTY 1 Year Limited **TESTING LABORATORY Underwriters Laboratories** LISTING STANDARD ANSI / UL 1484. Fourth Edition.

OWNERS REPLACEMENT RECORD

Replace this SAFE-T-ALERTTM propane Detector within 5 years, of the production date on the back of the Detector. **Production Date Replace Date**

Installer	

NOTE: The replacement date indicates the date beyond which the device may no longer detect accurately. Replace the Detector immediately.

LIMITED PRODUCTS WARRANTY

MTI INDUSTRIES, INC. Warrants to the original purchaser that this Detector will be free from defects of material or workmanship for a period of one (1) year. If defective in original materials or workmanship and returned, delivery costs prepaid, MTI INDUSTRIES, INC., will repair or replace this product free of charge.

LIMITS OF WARRANTY

Repair or replacement is your exclusive remedy under this limited warranty or any other warranty (including any implied warranty of merchantability for a particular purpose). Any and all implied warranties or merchantability or fitness for a particular purpose is limited to the warranty period from the original date of purchase. MTI INDUSTRIES, INC., its dealers and distributors shall in no case be responsible or in any way liable for any incidental or consequential damages for any reason. Some states do not allow the limitation or exclusion of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights that may vary from state to state.

WARRANTY RETURN POLICY

Warning-opening this product for any reason voids the warranty. There are no user serviceable parts in the case. This Detector requires an authorization number (RA) for repair or replacement. Call MTI for a RA number. Pack the Detector carefully in a padded container. Include the RA number, an explanation of the problem, the original dated sales receipt, and your return address. Send, shipping prepaid, to: MTI Industries, Inc. 31632 N. Ellis Drive Bldg. 301 Volo, IL 60073 Customer Service Number: 800-383-0269 e-Mail info@mtiindustries.com www.Safe-T-Alert.com

© 2007 MTI INDUSTRIES, INC.